

---

INSTRUCTIONS

---

# XTRASUN<sup>®</sup>

---

VERTICAL REFLECTOR

---



XT45V

# INSTRUCTIONS

## ASSEMBLY INSTRUCTIONS

1. Set aside the cone-shaped mogul housing and lay the four reflector pieces on a piece of carpet so you don't scratch the surfaces. Overlap the edges of the two pieces, lining up the holes. Insert screws from the bottom up and attach nuts. After four pieces are attached, pull the reflector up into a cone and insert the remaining four screws. Secure the screws by tightening all the nuts.
2. Unscrew the mounting ring from the included All System Cordset.
3. Slide the All System Cordset into mounting ring, fastening location A to ring at location 3 as noted on side of cordset (see cordset instructions for location A).
4. Align hole and slot on the mounting ring with the holes on the housing.
5. Take the two eyebolt/nut combinations out of the hardware bag and make sure their nuts are threaded all the way up the neck of each eyebolt.
6. Insert the eyebolts down through the mounting ring and housing.
7. Screw on the two locknuts from the hardware bag, from inside the housing. Make sure the eyebolts are aligned parallel so the hanger will insert easily.
8. Hand-tighten the locknuts from inside the housing. Using a crescent wrench or pliers, firmly tighten the eyebolt nut on top of the mounting ring.
9. Slide the reflector over the housing and cordset.
10. Insert the hanger ends into each eyebolt.
11. Use a strong cord or chain to hang the fixture and run it through a strong eyebolt or closed swag hook in the ceiling. **DO NOT HANG THE FIXTURE BY THE POWER CORD!**
12. Route the power cord up and away from the light to another hook (not provided) and down the wall to the ballast location.
13. Now, making sure the unit is still unplugged, screw the bulb in carefully so it is firm but not too tight. Make sure the ballast is sitting on a firm, dry surface.

